

Technical Specifications
of
Multi Function Meter
(SPRM300)



Class 0.5S

Sai PowerrZerve
29/3B , Rajalakshmi Nagar, 1st Main Road,
Velachery Bye Pass, Chennai – 600 042.
Website : www.spowerz.com
Email : info@spowerz.com
Phone : 044 - 43192660

General Specifications

1) GENERAL:

- Meter measures Active, Reactive, Apparent energy on 3 phase 4 wire system,
- All four quadrant measurement for MD, KWh, KVAh, KVArh (lag and lead) are measured and stored in four energy accumulators,
- Parameters can be viewed through 7 segment LED (2 row),
- Soft Keys are provided to stop, scroll, edit and to view the parameters,
- RTC with battery backup is used for time keeping and has a calendar of 100 years,
- Power Line Communication can be done using RS485 communication with MODBUS RTU,

2) METER FEATURES:

2.1) Display Details:

- 7 segment (2*4 digits) LED type – The parameters are calculated by the meter are displayed,
- Selectable Parameters – Can select any out of 31 parameters.
- Scroll rate – The scroll rate of the display parameter scroll in steps of 4secs.
- Keys are provided to stop, scroll, edit and to view the particular parameter.

2.1.1) Display Parameters:

- Time,
- Date,
- System,
- Meter ID with Phase Sequence,
- PT Primary,
- PT Secondary,
- CT Primary,
- CT Secondary,
- Frequency (Hz.),
- Cumulative – RYB – Active Energy (KWh),
- Cumulative – RYB – Apparant Energy (KVAh),
- Cumulative – RYB – Reactive Energy (KVArh Lag),
- Cumulative – RYB – Reactive Energy (KVArh Lead),
- Average Power Factor – RYB phase,
- Power ON hour,
- Load ON hour,

- Voltage L-N (R,Y,B) (V),
- Average Voltage (V),
- Average Voltage (V),
- Phase to Phase Voltages L-L (RY,YB,RB)
- Current (R, Y, B),
- Average Current,
- Power Factor (R, Y, B),
- Combined Power Factor (RYB),
- Instant Active Power – KW – R,Y,B,
- Instant Reactive Power – KVA_r – R,Y,B,
- Instant Apparent Power – KVA – R,Y,B,
- Instant – KW – RYB,
- Instant – KVA_r – RYB,
- Instant – KVA – RYB,
- Rising Demand – KW / KVA,
- Maximum Demand – KW / KVA,

2.2) Key Features:

- The Parameter setup can be done through 3 nos. of soft keys on front fascia,
- Keys on the front panel is used to
 - ✓ scroll, increment, decrement through display parameter,
 - ✓ to set the Meter ID,
 - ✓ PT Primary, PT Secondary,
 - ✓ CT Primary, CT Secondary values,
 - ✓ Time, Date,
 - ✓ MD Reset, Energy Reset,
 - ✓ Change Password
- Press scroll key once the parameter set is completed, this allows to view the parameters one after the other automatically (change over time period is 4 secs). If this is not done auto scroll will not happen.

2.3) Rear Terminal Details:



Note:

- (i) Field Programmability of the meter is optional based on the customer requirement,
- (ii) Each meter is given a unique number at the factory.

2.5) Safety Precautions:

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Apply appropriate personal protective equipment (PPE) and follow safe electrical work practices.
- Only qualified electrical workers should install this equipment. Such work should be performed only after reading this entire set of instructions.
- If the equipment is not used in a manner specified by the manufacturer, the protection provided by the equipment may be impaired.
- NEVER work alone.
- Before performing visual inspections, tests, or maintenance on this equipment, disconnect all sources of electric power.
- Assume that all circuits are live until they have been completely de-energized, tested, and tagged.
- Pay particular attention to the design of the DC power system.
- Consider all sources of power, including the possibility of back feeding.
- Turn off all power supplying the dc energy meter and the equipment in which it is installed before working on it.
- Always use a properly rated voltage sensing device to confirm that all power is off.
- Before closing all covers and doors, inspect the work area for tools and objects that may have been left inside the equipment.
- The successful operation of this equipment depends upon proper handling, installation, and operation.
- Neglecting fundamental installation requirements may lead to personal injury as well as damage to electrical equipment or other property.
- High voltage testing may damage electronic components contained in the dc energy meter.
- Ensure that no wiring strands are straying outside after connecting the wires.
- DC Energy Meter should be installed in a suitable electrical enclosure.

Failure to follow these instructions will result in death or serious injury

Technical Specifications

Accuracy	: Class 0.5s
System type	: 3 Phase 4 Wire
Input Voltage	: 3 x 240 VAC
Resolution	: 0.01 (for Combined kWh, kVAh)
Display	: Multi Parameter LED (2 ROW)
Auxiliary Supply	: 85 – 265 VAC
Voltage PT	: Primary side – Programmable (100V – 33KV) : Secondary side – 100 to 440 V
Current CT	: Primary side – Programmable (5A – 9999A) : Secondary side – 1 or 5A
Starting Current	: 10mA
Power Factor	: 4 quadrant operation
Frequency	: 50Hz, $\pm 5\%$
Communication	: RS485 Communication with MODBUS RTU in external integration with Power Line Communication
Temperature	: Operating Temp. – (-10 to 55) $^{\circ}$ C Storage Temp. – (-20 to 70) $^{\circ}$ C Humidity 5 to 95% RH at 50 $^{\circ}$ C (Non-Condensing)
Dimension	: (L 75 x W 55x H 110) mm (Inclusive of connector)
Mounting	: Panel Mountable
Connector Type	: Screw type terminals (BootLug 2.5mm)
Weight	: 350gms. (app.)